


WST-CR-SSL-60



DOWNLOAD HERE



whiskerseeker.com

NO.	PART DESCRIPTION	PART CODE	NO.	PART DESCRIPTION	PART CODE	NO.	PART DESCRIPTION	PART CODE
1	Left casting control cap	WST-BC-100	22	Bushing	WST-BC-121	47	Drive Washer	WST-BC-146
2	Washer	WST-BC-101	23	Level Wind Assembly	WST-BC-126	48	Drive Gear	WST-BC-147
3	O-Ring	WST-BC-102	24	Level Wind Pawl	WST-BC-127	49	Drag Washer	WST-BC-148
4	Bushing	WST-BC-103	25	Level Wind Nut	WST-BC-128	50	Key Washer	WST-BC-149
5	Click switch	WST-BC-104	26	Line Alarm Cog Wheel	WST-BC-129	51	Drag Washer	WST-BC-150
6	Washer	WST-BC-105	27	Ball Bearing	WST-BC-130	51-1	Drag Washer	WST-BC-151
7	Left Sideplate Assembly	WST-BC-106	28	Spool	WST-BC-131	52-1	Ear Washer	WST-BC-152
8	Clicker pawl	WST-BC-107	29	Spool Shaft	WST-BC-132	53	Key Washer	WST-BC-153
9	Spring	WST-BC-108	30	Washer	WST-BC-133	55	Spring Washer	WST-BC-154
10	Pin	WST-BC-109	31	Centrifugal Brake Support	WST-BC-134	56	Right Sideplate Assembly	WST-BC-155
11	Screw	WST-BC-110	32	Brake Block	WST-BC-135	59	Clip Plate	WST-BC-156
12	Washer	WST-BC-111	35	Plate	WST-BC-136	60	Right Casting control Cap	WST-BC-157
13	Oscillation cog Wheel	WST-BC-112	36	Release Trigger	WST-BC-137	61	Double Handle Assembly	WST-BC-158
14	E-Clip	WST-BC-113	37	Clutch Plate	WST-BC-138	63	Washer	WST-BC-160
15	Clicker retainer	WST-BC-114	38	Pinion Gear	WST-BC-139	64	Screw	WST-BC-161
16	E Clip	WST-BC-115	39	Yoke	WST-BC-140	65	Star Drag	WST-BC-162
17	Spring	WST-BC-116	40	A/R Pawl	WST-BC-141	66	Spacer	WST-BC-163
18	Lock Plate	WST-BC-117	42	Support Plate	WST-BC-142	67	Handle Nut	WST-BC-164
19	Frame Assembly	WST-BC-118	43	Spring Plate	WST-BC-143	68	Handle Nut locker	WST-BC-165
20	Worm Shaft Assembly	WST-BC-119	44	Spring Washer	WST-BC-144	69	Screw	WST-BC-166
21	Line Guide	WST-BC-120	45	Drive Shaft	WST-BC-145			